






















## TDI SPARE PART LIST-TPM MACHINE (FOR CUSTOMER)

1/3/2017

Type	#	TDI Part #	Description	Picture
Bearing	1	BRN-015	TGL3 Encoder end Bearing, TPM1/GTW8M Sheave Side Bearing	
	2	BRN-016	TPM1/GTW8M Encoder End Bearing	
	3	BRN-017	TPM2/3/4/GTW3M/MH/XL Bearing	
Oil Seal & Oring	4	ORN-011	TPM2/3/4/GTW3M/MH/XL Sheave front O-ring	
	5	OSL-012	TPM2/3/4/GTW3M/MH/XL Front and Back Oil Seal	
Main Drive Sheave	6	MSV-TPM1-8mm	TPM1/GTW8M Drive Sheave -4X8mmX14mm(pitch)X340-V40/92-HRC50, including 2 Pins and tag installed	
	7	MSV-TPM2/3-8mm	TPM2/3/GTW3M/MH Drive Sheave -7X8mmX14mm(pitch)X340-V40/92-HRC50, including 2 Pins and tag installed	
	8	MSV-TPM2/4-10mm	TPM2/4/GTW3M/MH/XL Drive Sheave -6X10mmX16mm(pitch)X400-V40/92-HRC50, including 2 Pins and tag installed	
Brake	9	ENBK-TPM1-001	TPM1/GTW8M Brake Assembly with 2 tags (normal and emergency)	
	10	ENBK-TPM1-002	TPM1/GTW8M Brake Pad	
	11	ENBK-TPM-003	TPM2/GTW3M-8mm Normal and Emergency (1 Unit) , TPM4/GTW3XL Emergency (2 units) with 2 tags (normal and emergency)	
	12	ENBK-TPM-004	TPM2/GTW8M-10mm, TPM3/GTW3MH Normal and Emergency Brake, TPM4/GTW3XL Normal with 2 tags (normal and emergency)	
	13	ENBK-TPM1-Switch	Brake Switch Kit - TPM1/GTW8M, Burgess V4NSY10-330mm and 1000mm, pair, with screws	
	14	ENBK-TPM2/3/4-Switch	Brake Switch Kit - TPM2/3/4/GTW3M/MH/XL, Burgess V4Ns-1000mm with screws	
	15	ENBK-TPM2/3/4-Plate	Brake self centering plate kit - TPM2/3/4/GTW3M/MH/XL Machines	
Encoder	16	ENC-Gearless-001	Heidenhain 413 Encoder	

<b>Encoder</b>	17	ENC-TPM1-Cover	TPM1/GTW8M Encoder Cover	
<b>Junction Box</b>	18	JUN-TPM1-001	TPM1/GTW8M Machine Junction Box Assembly	
	19	JUN-TPM-002	TPM2/GTW3M Machine Junction Box Kit	
	20	JUN-TPM-003	TPM3/4/GTW3MH/XL Machine Junction Box Kit	
	21	JUN-TPM1-TER	Motor Terminal Block for TPM1/GTW8M	
	22	JUN-TSM/TPM2/3/4-TER	Motor Terminal Block for TSM, TMGL1, TMGL2, TMGL2A, TPM2/3/4/GTW3M/MH/XL	
<b>Sheave Guard</b>	23	SHG-TPM1-8mm	TPM1/GTW8M Drive Sheave Guard Kit	
	24	SHG-TopTPM2/3-8mm	TPM2/3/GTW3M/MH-8mm Top Sheave Guard Kit	
	25	SHG-SideTPM2/3-8mm	TPM2/3/GTW3M/MH-8mm Side Sheave Guard Kit	
	26	SHG-TopTPM2/4-10mm	TPM2/4/GTW3M/XL-10mm Top Sheave Guard Kit	
	27	SHG-SideTPM2/4-10mm	TPM2/4/GTW3M/XL-10mm Side Sheave Guard Kit	
<b>Grease Nozzle</b>	28	GRN-M8	Grease Fitting Nozzle, M8X1	
<b>Grease Drain Plug</b>	29	GRP-M8	Grease Drain Plug, M8X1	